


BT-P4P

Data sheet


Module for push buttons

Ref. BT-P4P




General description

- The BT-P4P module allows you to connect four push buttons to a BTZ module.
- The device has two terminals for its connection to the BTZ module (DA, DA), two ports or channels (IN0, IN1, IN2 e IN3) and a common terminal.
- The module is served by cables with a 0.5mm² section and 200m length. The IN0, IN1, IN2 and IN3 terminals can't be extended by an additional cable.
- You will find two stickers when you open the packaging, one to be placed on the casing of the device and another to be placed on the location plan, which will inform about the location of the device once installed.




Connection scheme

Four push buttons



One push button



Sede central / Headquarters

Parque Tecnológico de Asturias. C/ Ablanal, 1
33428 Llanera (Asturias).
España / Spain
normalink.es